

Quick Start Guide for Windows

1. Check your system meets requirements.

Refer to User Guide Page **8 (2-6 System Requirements)**.

Refer to User Guide Page **31(8.Make sure USB port is set ready)**.

2. Connect CF03U to your PC. Refer to User Guide page **11**.

3. Install driver in CD-ROM to your system. Refer to User Guide page **12**.

Quick Start Guide for Macintosh

1. Check your system meets requirements.

Refer to User Guide Page **8 (2-6 System Requirements)**.

Refer to User Guide Page **48 to make sure there is [File Exchange] in your Mac.**

2. Install driver in CD-ROM to your system. Refer to User Guide page **48**.

3. Connect CF03U to your PC. Refer to User Guide page **50**.

Trouble when you use CF03U with Power Macintosh G4

As of 7th of December in 1999, there is a problem that when you use CF03U with Apple Power Macintosh G4(AGP model),your system will not shut down.

[Macintosh machines which cause such a problem]

Power Macintosh G4 400MHz-AGP(M7824J/A)

Power Macintosh G4 450MHz-AGP(M7825J/A)

[The problem in detail]

When you try to shut down your Power Macintosh G4 (AGP model) with CF03U connected, your system will start up automatically after your system shuts down. You just can not shut down your Power Macintosh G4 (AGP model).

[How to deal with this problem]

After disconnect CF03U from Apple Macintosh G4(AGP model),you can shut down.

[About tech support,etc]

This model is incompatible with CF03U.

We don't tech support for Apple Macintosh G4(AGP model).

Thank you.